

## The SilberPfeil®NonStop This is how it's done:

### Preparation:

Open the fresh pack, take out the nets and put it in enough cold water to remove the salt. After ca. 15 minutes change the water and let the nets soak overnight (12 hours) at max. 20°C in fresh, cold water (min. 2 litres per net)

### Application

- 1) Take out the nets and drain the water, the knot has to point upwards to prevent water bowls.
- 2) Tear open the net and put it next to the filling machine. Take the tube, tighten it and pull it onto the filling horn. The gripe hole must point to the side of the machine.
- 3) Pull the end of the casing slightly forward and then pull out the to the back side gently and steadily.

Now you can start the filling.



**Attention:** SilberPfeil®NonStop has to be used in cold condition, use only cold water for soaking (max. 20°C)!!! Silberpfeil®NonStop have to be filled with soft casing breaks only. If there is no soft break available, please open your break as much as possible to enable the welding spot passing through the break smoothly. For proper adjustment of the filling machine, the casing break and the holding device, please contact the CDS application technicians.

You can contact the CDS-service team at:  
+49 (0) 7951-391-0